



What an average Bath Pro Job consists of:

- Put down drop sheets from front door to bathroom
- Bring in tools and tool bags
- Turn off main water to home
- Removal of old wall surround (Tiles, barker board, plastic, acrylic)
- Removal of required drywall
- Removal of old Tub/Shower
- Sweep floor to minimize dust
- Removal of old taps
- Switch water supply lines over from copper to Pex
- Install new drain and new P-trap where possible
- Replace subfloor if required (price may increase, price is determined in time)
- Sweep floor to minimize dust
- Install new tub or shower base
- Tub is mounted to almost every stud to be secure and stable and perfectly level
- Install new tap system to customers preferences, (height of shower head, control lever height and location)
- Install backing for grab bars, shower doors, and anything else that will require backing
- Turn water on to house and pressure test new valve and shower system
- Install backing for grab bars to customers preferred location
- Install new aqua board (moisture resistant drywall) in tub area
- Install new custom cut wall surround to fit perfectly
- Install shelving unit(s) to customers preference
- Install new curved shower rod or shower doors, if requested
- Sweep floor to minimize dust
- Professionally seal walls to tub with commercial grade caulking
- Clean up bathroom and remove work tools and bags
- Tidy up outside and remove all waste
- Provide customer with warranty sheet and receipt
- Do final inspection with customer

Thank customer and say goodbye!